



When you try to disconnect the tubing from a 1/2" size Brass Push Tee from the middle part, you might not be able to disconnect it because of the design of with two faceplates.





Open the clamp fork little wider and position like this to remove the tubing



The faceplate with size markings must be faced down and use only this faceplate to disconnect the tubing